



## X/Y Axis Clearances





- 1. The table shown is at XY home, the dashed line is the table at max XY travels
- Measurements are from the edge of the table to the nearest obstruction
  Dimensions shown are at the top of the table, dimensions are reduced as the height increases (5 degree slope inside the sheet-metal)
- 4. Dimensions are symmetrical unless otherwise stated

## Z Axis Clearances


- 1. P-Cool dimension varies based on P-Cool position
- 2. Refer to the page on tool changer dimensions for tool changer heights








**DETAIL B** 




VF-1


**Tool Changers** 

VF-1 Revision C Page 5 of 5 March 2016







	24+1 Pocket	
Α	22.5in	572mm
В	10in	254mm
С	3in	76mm
D	21in	533mm
Е	24in	610mm



## Umbrella Tool Changer Travels





The Umbrella Tool Changer moves in towards the spindle to do a tool change.